

USB2.0 150M Extender Kit

Specifications:

Transmitter interface:		
Upstream port	USB2.0 type B receptacle	
Downstream port	RJ45 Jack	
Downstream interface:		
Upstream port	RJ45 Jack	
Downstream port	USB2.0 type A receptacle	
Power :		
Transmitter unit	Bus- Powered (5VDC from USB port)	
Receiver	DC 5V/3A adapter	
Functions :		
	*extension cat.5e/cat6 LAN cable up to 150M	
	*Compliant USB 2.0/1.1	
	*support plug- and- play, don't need install driver	
	*support Webcam resolution up to 1080p	

Physical Specification :	
Dimensions	Transmitter unit : 32.2(W)x25.4(H)x67.3 (L) mm
	Receiver unit : 32.2(W)x25.4(H)x67.3 (L) mm
Weight	Transmitter unit: 87g
	Receiver unit :86g
Housing Material	Metal


System Environments:

- * Microsoft Windows XP,Vista,7,8,8.1,10(32 or 64-bit), Mac OS X / LUNIX kernal3.x above compatible
- * USB2.0 type A receptacle

Package:

- *Transmitter unit*1
- *Receiver unit*1
- *AC adapter (DC 5V/3A)*1
- *USB2.0 A-B cable length:600mm*1

Application:



Installation:

- Step1. Connect Cat.5e/Cat.6 cable from Transmitter unit to Receiver unit.
- Step2. USB device connect to Receiver unit USB port.
- Step3. 5V/3A adaptor Plug in Receiver unit DC Jack.
- Step4. Connect USB2.0 A-B cable from PC/NB to Transmitter unit.

The Extender kit installs fine, the Receiver unit inductor GREEN LED will be flash of RJ45 Jack.

Note: Cat.5e/Cat.6 LAN cable must be follow TIA/EIA-568-A or TIA/EIA-568-B standard.